


# Kia / Hyundai -- SWC Interface

 In order to prevent ESD damage, the W/R Jack must be connected before plugging the connectors on car side

